





Scale: 1 : 50



1. ASSUME TOP OF FLOOR SLAB ELEVATION AS +0.000.
FOR FLOOR SLAB ELEVATION SEE BUILDING SECTION DRAWING.
2. ALL DIMENSIONS ARE IN METERS AND ALL ANGLES ARE IN DEGREES LOCATED 90° BY GRID LINE, UNLESS NOTED OTHERWISE.
3. REFER TO STRUCTURAL DRAWINGS FOR FURTHER
COLUMN, WALL AND ROOM AREA DETAILS.
4. FOR ELEVATOR SHAFT SIZE AND OPENING REFER TO
LANDSCAPE DRAWING.
5. CONTRACTORS TO CONFIRM STAIR LOCATION WITH
PRECAST STAIR MANUFACTURER. FOR STAIR MIDS
LANDSCAPE REFER TO STAIR AND RAMP DETAILS DRAWINGS.
6. CONTRACTORS TO CONFIRM STAIR LOCATION WITH
PRECAST STAIR MANUFACTURER. FOR STAIR MIDS
LANDSCAPE REFER TO STAIR SECTION OR A-A - SERIES DRAWINGS.
7. REFER TO LANDSCAPE DRAWINGS FOR PLANTER WALL
HEIGHT, HEIGHT DETAILS, FINISHES, MATERIALS
AND GENERAL DETAILS AND DIMENSIONS.
8. CONTRACTORS TO CONFIRM STAIR AND RAMP FOR
HORIZONTAL SHAFT OPENING REDS IN WALLS
AND STAIR OPENING REDS IN WALLS.
9. CONTRACTORS TO CONFIRM STAIR AND RAMP FOR
LOUVER AND ENJOYABLE OPENING SIZES
AND RAMP DETAILS.
10. REFER TO ARCHIVAL DRAWINGS FOR SURVEYED LOCATIONS
AND DIMENSIONS. CONTRACTORS TO VERIFY WHICH ARE
TO BE CONFIRMED BY THE SURVEYOR/ON SITE.
11. REFER TO SITEWORK/GEOTECHNICAL ENGINEERS DRAWING
FOR STAIR OPENING REDS IN WALLS AND STAIR OPENING
REDS TO BE CONFIRMED BY THE SURVEYOR/ON SITE.

[illegible]